



Preparing for your Refinishing Project

NOTE: Your surface will need 48 hours to cure after the completion of the project, before using.

1. The project space must have running water and electricity on the day of the project.
2. All faucet drips and drain leaks must be repaired prior to the project date.
3. We recommend faucets, valves, trim kits, etc. be removed prior to the project and reinstalled 48 hours after the completion of the project.
4. Remove everything from the bathroom prior to my partners arrival ie. soaps, shampoos, trashcans, towels, plungers, everything on the vanity countertop, all pictures hanging on the walls, rugs, hanging plants, shower curtains, etc... If the project is not in a bathroom, remove all items within a 10 foot radius around the area which will be worked on, this would include stoves and refrigerators if they are next to a kitchen counter that is being refinished.
5. Give the bathroom a good wipe down removing dust, hair and spider webs before he arrives so that he has a great space to be able to create beautiful results.
6. Scrub as much soap scum, mildew and calcium build-up off the surface as possible prior to the project.
7. Do not paint the walls or cabinets less than 2 weeks prior to the project date.
8. No other work can be done in the room where the project is taking place.
9. No dusty projects can take place anywhere in the home on the day of the project.
10. We use Low VOC, FDA and EPA products that do however have an odor that is offensive to some people and animals. Plan your days activities accordingly to have the ability to vacate the premises if needed.